

# InterComfort™ GR Installation Instructions

InterComfort GR can be used with Interface GlasBac®, GlasBacRE and Graphlar® backings for added underfoot comfort and sound reduction.

1. Remove/smooth any sharp objects or projections from the surface of the slab to prevent puncturing or tearing the InterComfort GR sheet.
2. The slab should be swept to remove dust, debris and tacky adhesive residue.
  - \* Sweep using a sweeping compound (do NOT use oil based or silicone based sweeping compounds) or vacuum with an industrial vacuum.
  - \* Tacky adhesive residue must be removed or reduced and the residual encapsulated.
  - \* Dry adhesive residue may remain on the surface if it is smooth, level and otherwise in compliance with Interface GlasBac and GlasBacRE or Graphlar modular carpet installation specifications.
3. Start in a corner and unroll the InterComfort GR pad, making sure to keep material flat to the floor (no wrinkles).
4. Roll out the next row in the same manner, butting tightly to the previous roll. **Do not overlap.** Secure seams every 6' with an Interface TacTiles® connector. Cutouts around columns, utilities, etc, should be about 1/4 inch.
5. Smooth out pockets of trapped air.
6. Continue laying rows of InterComfort GR until the desired coverage is achieved.
7. Protect from other trades.
8. Once InterComfort GR is installed, installation of the modular carpet follows the standard installation instructions for Interface GlasBac and GlasBacRE or Graphlar backed modular carpet using the Interface TacTiles installation system.

**InterComfort™ GR** Cushion solution designed to provide underfoot comfort in guest rooms.

