

InterComfort™ PS+ Installation Instructions

InterComfort PS+ can be used with Interface GlasBac® and GlasBacRE or Graphlex® and Graphlar® backings for added underfoot comfort and sound reduction.

1. Remove/smooth any sharp objects or projections from the surface of the slab to prevent puncturing or tearing the InterComfort PS+ sheet.
2. Sweep the slab to remove dust, debris and tacky adhesive residue.
 - * Sweep using a sweeping compound (do NOT use oil based or silicone based sweeping compounds) or vacuum with an industrial vacuum.
 - * Tacky adhesive residue must be removed or reduced and the residual encapsulated.
 - * Dry adhesive residue may remain on the surface if it is smooth, level and otherwise in compliance with Interface GlasBac and GlasBacRE or Graphlex and Graphlar modular carpet installation specifications.
3. Spread a bead of pad adhesive in a serpentine pattern over the floor, as well as around the perimeter and at the seams. Roll out a 20-30' section of the

InterComfort pad fuzzy side down (smooth side up.)

4. Lay the InterComfort PS+ pad in the wet adhesive rough side down, making sure to keep the material flat to the floor (no wrinkles). The smooth side should be facing upward.
5. Roll out the next row in the same manner, butting tightly to the previous roll. **Do not overlap.** Cutouts around columns, utilities, etc., should be about 1/4 inch.
6. Smooth out pockets of trapped air.
7. Continue laying rows of InterComfort PS+ until the desired coverage is achieved.
8. Protect from other trades.
9. Once the InterComfort PS+ is installed, installation of the modular carpet follows the standard installation instructions for Interface GlasBac and GlasBacRE or Graphlex and Graphlar backed modular carpet using the Interface TacTiles® installation system. Because the TacTiles connectors are being used over the InterComfort PS+, be sure to cut the tiles net to the wall.

InterComfort™ PS+ Cushion solution designed to provide underfoot comfort in public spaces.

